

WASTE WATER BALL VALVE KIT

The AIRE Environmental Waste Water 2" Ball Valve Kit includes everything you'll need to connect Waste Water Bladders to 2" hose*. Its quarter turn ball valve makes controlling flow a breeze.

**Hose must be equipped with a female camlock fitting.*

WHAT YOU NEED TO KNOW

The components below are laid out in order. The top row threads into the bulkhead on the top of the bladder and the bottom row threads into the discharge bulkhead on the side of the bladder.

Instructions

1. Wrap any exterior threads with included Teflon tape.
2. Thread the components together.
3. Thread the completed assemblies into the Waste Water Bladder.

Note:

Be careful not to overtighten the completed assemblies, doing so could damage the threads and/or bladder.



Need a custom size, color or design? Call 1 (800) 247-3846.

